


JVC

COMPACT COMPONENT SYSTEM

CA-MXGB6 CA-MXGB5



COMPACT
disc
DIGITAL AUDIO

R-D-S

INSTRUCTIONS

Warnings, Cautions and Others

IMPORTANT for the U.K.

DO NOT cut off the mains plug from this equipment. If the plug fitted is not suitable for the power points in your home or the cable is too short to reach a power point, then obtain an appropriate safety approved extension lead or consult your dealer.

BE SURE to replace the fuse only with an identical approved type, as originally fitted.

If nonetheless the mains plug is cut off ensure to remove the fuse and dispose of the plug immediately, to avoid a possible shock hazard by inadvertent connection to the mains supply.

If this product is not supplied fitted with a mains plug then follow the instructions given below:

IMPORTANT:

DO NOT make any connection to the terminal which is marked with the letter E or by the safety earth symbol or coloured green or green-and-yellow.

The wires in the mains lead on this product are coloured in accordance with the following code:

Blue : Neutral
Brown : Live


As these colours may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

IF IN DOUBT - CONSULT A COMPETENT ELECTRICIAN.

Caution — I STANDBY/ON switch!

Disconnect the mains plug to shut the power off completely. The  I STANDBY/ON switch in any position does not disconnect the mains line. The power can be remote controlled.


CAUTION

To reduce the risk of electrical shocks, fire, etc.:

1. Do not remove screws, covers or cabinet.
2. Do not expose this appliance to rain or moisture.

IMPORTANT FOR LASER PRODUCTS

1. CLASS 1 LASER PRODUCT
2. **CAUTION:** Do not open the top cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
3. **CAUTION:** Visible and invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
4. REPRODUCTION OF LABEL: CAUTION LABEL, PLACED INSIDE THE UNIT.



CAUTION

- Do not block the ventilation openings or holes.
(If the ventilation openings or holes are blocked by a newspaper or cloth, etc., the heat may not be able to get out.)
- Do not place any naked flame sources, such as lighted candles, on the apparatus.
- When discarding batteries, environmental problems must be considered and local rules or laws governing the disposal of these batteries must be followed strictly.
- Do not expose this apparatus to rain, moisture, dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

Caution: Proper Ventilation

To avoid risk of electric shock and fire, and to prevent damage, locate the apparatus as follows:

1 Front:


No obstructions and open spacing.

2 Sides/ Top/ Back:

No obstructions should be placed in the areas shown by the dimensions below.

3 Bottom:

Place on the level surface. Maintain an adequate air path for ventilation by placing on a stand with a height of 10 cm or more.



* About the cooling fan

A cooling fan is mounted on the rear panel of the unit to prevent abnormal temperature inside the unit, thus assuring normal operation of the unit. The cooling fan automatically starts rotating to intake external cool air when the volume is increased up to more than a certain level.

SAFETY INSTRUCTIONS

“SOME DOS AND DON'TS ON THE SAFE USE OF EQUIPMENT”

This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured.

☆☆

Do read the operating instructions before you attempt to use the equipment.

Do ensure that all electrical connections (including the mains plug, extension leads and interconnections between pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug when making or changing connections.

Do consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment.

Do be careful with glass panels or doors on equipment.

☆☆

DON'T continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way—switch off, withdraw the mains plug and consult your dealer.

DON'T remove any fixed cover as this may expose dangerous voltages.

DON'T leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation or has a standby mode.

Switch off using the switch on the equipment and make sure that your family know how to do this.

Special arrangements may need to be made for infirm or handicapped people.

DON'T use equipment such as personal stereos or radios so that you are distracted from the requirements of traffic safety. It is illegal to watch television whilst driving.

DON'T listen to headphones at high volume as such use can permanently damage your hearing.

DON'T obstruct the ventilation of the equipment, for example with curtains or soft furnishings.

Overheating will cause damage and shorten the life of the equipment.


DON'T use makeshift stands and NEVER fix legs with wood screws — to ensure complete safety always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions.

DON'T allow electrical equipment to be exposed to rain or moisture.

ABOVE ALL

- NEVER let anyone, especially children, push anything into holes, slots or any other opening in the case -this could result in a fatal electrical shock.;
- NEVER guess or take chances with electrical equipment of any kind
- it is better to be safe than sorry!

Introduction



We would like to thank you for purchasing one of our JVC products. Before operating this unit, read this manual carefully and thoroughly to obtain the best possible performance from your unit, and retain this manual for future reference.

About This Manual

This manual is organized as follows:

- The manual mainly explains operations using the buttons and controls on the unit. You can also use the buttons on the remote control if they have the same or similar names (or marks) as those on the unit. If operation using the remote control is different from that using the unit, it is then explained.
- Basic and common information that is the same for many functions is grouped in one place, and is not repeated in each procedure. For instance, we do not repeat the information about turning on/off the unit, setting the volume, changing the sound effects, and others, which are explained in the section “Common Operations” on pages 9 to 11.
- The following marks are used in this manual:



Gives you warnings and cautions to prevent damage or risk of fire/electric shock. Also gives you information which is not good for obtaining the best possible performance from the unit.



Gives you information and hints you had better know.

Precautions

Installation

- Do not grasp the control knobs when moving or carrying the unit.
- Install in a place which is level, dry and neither too hot nor too cold—between 5°C and 35°C.
- Install the unit in a location with adequate ventilation to prevent internal heat built-up in the unit.
- Leave sufficient distance between the unit and the TV.
- Keep the speakers away from the TV to avoid interference with TV.



DO NOT install the unit in a location near heat sources, or in a place subject to direct sunlight, excessive dust or vibration.

Power sources

- When unplugging from the wall outlet, always pull the plug, not the AC power cord.



DO NOT handle the AC power cord with wet hands.

Moisture condensation

Moisture may condense on the lens inside the unit in the following cases:

- After starting heating in the room
 - In a damp room
 - If the unit is brought directly from a cold to a warm place
- Should this occur, the unit may malfunction. In this case, leave the unit turned on for a few hours until the moisture evaporates, unplug the AC power cord, and then plug it in again.


Others

- Should any metallic object or liquid fall into the unit, unplug the unit and consult your dealer before operating any further.
- If you are not going to operate the unit for an extended period of time, unplug the AC power cord from the wall outlet.



DO NOT disassemble the unit since there are no user serviceable parts inside.

If anything goes wrong, unplug the AC power cord and consult your dealer.




Location of the Buttons and Controls	3
Front Panel	3
Remote Control	5
Getting Started	6
Unpacking	6
Putting the Batteries into the Remote Control	6
Connecting Antennas	6
Connecting Speakers	7
Connecting Other Equipment	8
Canceling the Display Demonstration	8
Common Operations	9
Turning On or Off the Power	9
Saving the Power Consumption While on Standby —ECO Mode	9
Setting the Clock	9
Selecting the Sources	10
Adjusting the Volume	10
Reinforcing the Bass Sound	10
Enjoying the Powerful Sound—RHYTHM AX	10
Selecting the Sound Modes	11
Turning On or Off the Key-touch Tone	11
Listening to the Radio	12
Tuning in to a Station—Auto Search	12
Presetting Stations	12
Tuning in to a Preset Station	12
Receiving FM Stations with RDS	13
Changing the RDS Information	13
Searching for Programs by PTY Codes (PTY Search)	13
Switching Temporarily to a Program Type of Your Choice	14
Playing Back CDs	15
Loading CDs	15
Playing Back CDs—All Disc and One Disc	15
Basic CD Operations	17
Changing the MP3 Playback Mode	19
Turning On or Off the Resume Play for MP3 Disc ..	19
Programming the Playing Order of the Tracks —Program Play	20
Playing at Random—Random Play	21
Repeating Tracks or CDs—Repeat Play	21
Prohibiting Disc Ejection—Carrousel Lock	21
Playing Back Tapes	22
Playing Back a Tape	22
Recording	23
Recording a Tape on Deck B	23
Dubbing Tapes	24
CD Synchronized Recording	24
Using the Timers	25
Using Daily Timer	25
Using Recording Timer	27
Using Sleep Timer	28
Timer Priority	28
Maintenance	29
Additional Information	30
Troubleshooting	31
Specifications	32


Location of the Buttons and Controls

Become familiar with the buttons and controls on your unit.

Front Panel



Display Window



See pages in the parentheses for details.

Front Panel

- 1 **⏻/I** STANDBY/ON button (9, 26, 27)
ECO button (9)
- 2 Standby lamp (9)
- 3 Carrousel
- 4 Display window
- 5 Remote sensor (5)
- 6 **REC** START/STOP button (23)
CD REC START button (24)
DUBBING button (24)
- 7 **REC** lamp (23, 24)
SOUND MODE lamp (11)
RHYTHM AX lamp (10)
- 8 **REPEAT** button (15, 17, 21)
PROGRAM (MP3 Resume on/off) button (19, 20)
RANDOM button (21)
- 9 **SOUND MODE** control (11)
RHYTHM AX control (10)
- 10 **AUX** button (10)
FM/AM button (10, 12)
CD **▶/||** (play/pause) button (10, 15 – 17, 20)
TAPE A **▶** (play) button (10, 22, 24)
TAPE B **▶** (play) button (10, 22, 24)
Pressing one of these buttons also turns on the unit.
- 11 **CLOCK/TIMER** button (9, 25 – 28)
SET/DISPLAY button (9, 12, 20, 25 – 28)
CANCEL/DEMO button (8, 9, 20, 25 – 28)
- 12 **PHONES** jack (10)
- 13 **TUNING +/-** buttons (12)
▶▶ / ◀◀ (fast forward/fast rewind) buttons (17, 22)
- 14 **■** (stop) button (15 – 17, 20 – 24)
BEEP button (11)
- 15 **Deck A** cassette holder (22, 24)
*Pressing the **▲** (open/close) portion opens the holder.*
- 16 **CD ▲** (Carrousel open/close) button (15 – 17, 19 – 21)
Pressing this button also turns on the unit.



- 17 **DISC CHANGE** button (15, 17)
- 18 Disc number buttons (CD1, CD2, and CD3) (16, 17, 20, 21, 24)
Pressing one of these buttons also turns on the unit.
- 19 **CD READY** lamps (CD1, CD2, and CD3) (16)
- 20 **SUBWOOFER LEVEL +/-** control (10)
- 21 **VOLUME** control (10)
- 22 **AUX** jack (8)
- 23 **PRESET +/-** buttons (12)
▶▶ / ◀◀ (forward search/reverse search) buttons (9, 17 – 21, 25 – 27)
- 24 **Deck B** cassette holder (22 – 24, 27)
*Pressing the **▲** (open/close) portion opens the holder.*

Display Window

- 1 **Timer** indicators
 - **DAILY** (daily timer), **SLEEP** (sleep timer), **REC** (recording timer), and **⌚** (timer) indicators
- 2 **GROUP** indicator
- 3 **TRACK** indicator
- 4 **RDS** indicator
- 5 **Main display**
 - Shows the source name, frequency, etc.
- 6 **NEWS** indicator
- 7 **INFO** indicator
- 8 **MP3** indicator
- 9 **Tape operation** indicators
 - **A/B** (operating deck), **REC** (recording), and **◀▶** (tape running) indicators
- 10 **PRGM** (program) indicator
- 11 **SOUND MODE** indicator
- 12 **WOOFER** indicator
- 13 **CD track number** indicators
- 14 **RANDOM** indicator
- 15 **REPEAT** mode indicators
 - **REPEAT**, **1**, **1 DISC**, **ALL DISC** indicators
- 16 **Tuner operation** indicators
 - **MONO** and **ST** (stereo) indicators
- 17 **Volume level, Subwoofer level and Sound Mode pattern** indicators



Remote Control



When using the remote control, point it at the remote sensor on the front panel.

Remote Control

- 1 BEEP ON/OFF button (11)
- 2 SLEEP button (28)
- 3 Number buttons (12, 18)
- 4 TAPE A ► (play) button (10, 22)
Pressing this button also turns on the unit.
- 5 VOLUME + button (10)
- 6 FM/AM button (10, 12)
Pressing this button also turns on the unit.
- 7 AUX button (10)
Pressing this button also turns on the unit.
- 8 SOUND MODE button (11)
- 9 FADE MUTING button (10)
- 10 ◀◀/◀◀ (reverse search/fast rewind) button (12, 17 – 19, 21, 22)
- 11 ■ (stop) button (15 – 17, 20 – 24)
- 12 ◻/◻ (play/pause) button (10, 15 – 17, 20)
Pressing this button also turns on the unit.
- 13 FM MODE button (12)
MP3 button (19)
- 14 TAPE B ► (play) button (10, 22)
Pressing this button also turns on the unit.
- 15 RHYTHM AX button (10)
- 16 CD ►/■ (play/pause) button (10, 15 – 17, 20)
Pressing this button also turns on the unit.
- 17 VOLUME – button (10)
- 18 DISC SKIP button (15, 17)
- 19 SUBWOOFER LEVEL + button (10)
- 20 ►►/►► (forward search/fast forward) button (12, 17 – 19, 21, 22)
- 21 SUBWOOFER LEVEL – button (10)
- 22 RDS operation buttons (13, 14)
 - DISPLAY MODE, SELECT +/–, and RDS MODE buttons

Unpacking

After unpacking, check to be sure that you have all the following items.


The number in the parentheses indicates the quantity of the pieces supplied.

- AM (MW) loop antenna (1)
- FM antenna (1)
- Remote control (1)
- Batteries (2)

If any is missing, consult your dealer immediately.

Putting the Batteries into the Remote Control


Insert the batteries—R6P(SUM-3)/AA(15F)—into the remote control, by matching the polarity (+ and –) on the batteries with the + and – markings on the battery compartment. When the remote control can no longer operate the unit, replace both batteries at the same time.



- DO NOT use an old battery together with a new one.
- DO NOT use different types of batteries together.
- DO NOT expose batteries to heat or flame.
- DO NOT leave the batteries in the battery compartment when you are not going to use the remote control for an extended period of time. Otherwise, it will be damaged from battery leakage.

Connecting Antennas

FM antenna



- 1 Attach the FM antenna to the FM [75 Ω] coaxial terminal.**
- 2 Extend the FM antenna.**
- 3 Fasten it up in the position which gives you the best reception, then fix it on the wall, etc.**




About the supplied FM antenna


The FM antenna supplied with this unit can be used as temporary measure. If reception is poor, you can connect an outdoor FM antenna.

To connect an outdoor FM antenna

Before connecting it, disconnect the supplied FM antenna.



AM (MW) antenna



1 Press and hold the clamp of the AM terminal on the rear of the unit.

2 Insert the end of the AM (MW) loop antenna cord into the terminal.

- If the AM (MW) loop antenna wire is covered with vinyl, remove the vinyl by twisting it as shown in the diagram.

3 Release the finger from the clamp.

4 Turn the AM (MW) loop antenna until you have the best reception.

To connect an outdoor AM (MW) antenna


When reception is poor, connect a single vinyl-covered wire to the AM terminal and extend it horizontally. (The AM (MW) loop antenna must remain connected.)



For better reception of both FM and AM (MW)

- Make sure the antenna conductors do not touch any other terminals and connecting cords.
- Keep the antennas away from metallic parts of the unit, connecting cords, and the AC power cord.

Connecting Speakers



1 Press and hold the clamp of the speaker terminal on the rear of the unit.

2 Insert the end of the speaker cord into the terminal.

Match the colors (polarity): Blue (+) to blue (+) and black (-) to black (-); red (+) to red (+) and black (-) to black (-).

- If the wire is covered with vinyl, remove the vinyl by twisting it as shown in the diagram.

3 Release the finger from the clamp.

IMPORTANT:

- Use only speakers with the same speaker impedance as indicated by the speaker terminals on the rear of the unit.
- DO NOT connect more than one speaker to one speaker terminal.




Connecting Other Equipment

You can connect audio equipment—used only as a playback device.



- DO NOT connect any equipment while the power is on.
- DO NOT plug in any equipment until all connections are complete.

To connect audio equipment



For playing the other equipment through this unit, connect between the audio output jack on the other equipment and AUX jack on the front of the unit by using a stereo mini plug cord (not supplied).



If the audio output on the other equipment is not stereo mini plug type

Use a plug adapter to convert the stereo mini plug to the corresponding plug of the audio output.


NOW you are ready to plug in the unit and other connected equipment.

Canceling the Display Demonstration

When connecting the AC power cord into a wall outlet, the unit automatically starts the display demonstration.

On the unit ONLY:

To cancel the display demonstration, press CANCEL/DEMO while the display demonstration is shown on the display.




When you press other buttons

The display demonstration stops temporarily. It will start automatically again (if no operation is done for 2 minutes) until you cancel it.

To start the display demonstration manually

Press and hold CANCEL/DEMO again for more than 2 seconds.




Common Operations


Turning On or Off the Power

To turn on the unit, press **STANDBY/ON** so that the standby lamp goes off.

POWER ON



To turn off the unit (on standby), press **STANDBY/ON** again so that the standby lamp lights up.



A little power is always consumed even while the unit is on standby.

To switch off the power supply completely, unplug the AC power cord from the AC outlet.




When you unplug the AC power cord or if a power failure occurs

The clock is reset to “-- : --” soon, while the tuner preset stations (see page 12) will be erased in a few days.

Saving the Power Consumption While on Standby—ECO Mode

You can save the power consumption while the unit is turned off (on standby).

To activate the ECO mode, press **ECO** while the unit is turned off (on standby). The display illumination (including the display demonstration) disappears.



To deactivate the ECO mode, press **ECO** again. The display illumination appears.

- Turning on the unit also deactivates the ECO mode.



About the ECO mode


While the ECO mode is activated, the display demonstration is canceled temporarily.

Setting the Clock

Before operating the unit any further, first set the clock built in this unit. You can set the clock whether the unit is on or off.


On the unit ONLY:

1 Press CLOCK/TIMER.



The hour digits start flashing on the display.

2 Press **▶▶▶ or **◀◀◀** to adjust the hour, then press SET/DISPLAY.**




The minute digits start flashing on the display.

- If you want to correct the hour after pressing SET/DISPLAY, press CANCEL/DEMO. The hour digits start flashing again.

3 Press **▶▶▶ or **◀◀◀** to adjust the minute, then press SET/DISPLAY.**


CLOCK OK



To check the clock time

Press and hold SET/DISPLAY for more than 2 seconds while playing any source.

- To return to the source indication, press SET/DISPLAY.




While the time indication appears on the display

If you press a button or turn a control, the time indication returns to the source indication.

To adjust the clock again

If you have adjusted the clock before, you need to press CLOCK/TIMER repeatedly until “CLOCK” is selected.

- Each time you press the button, the clock/timer setting modes change as follows:



If there is a power failure

The clock loses the setting and is reset to “-- : --.” You need to set the clock again.


Selecting the Sources

To listen to the radio, press FM/AM. (See page 12.)

To play back CDs, press CD ►/■. (See pages 15 – 21.)

To play back tapes, press TAPE A ► or TAPE B ►. (See page 22.)

To select the external equipment as the source, press AUX.



When you press the play button for a particular source (AUX, FM/AM, CD ►/■, TAPE A ►, and TAPE B ►), the unit turns on (and the unit starts playing the source if it is ready—COMPU PLAY CONTROL).

Adjusting the Volume


You can adjust the volume level only while the unit is turned on.

This function only affects the playback sound, not your recording.

Turn the **VOLUME** control clockwise to increase the volume or counterclockwise to decrease it.

- The volume level can be adjusted in 32 steps (VOL MIN, VOL 1 — VOL 30, and VOL MAX).

VOL 14



When using the remote control, press **VOLUME +** to increase the volume or press **VOLUME -** to decrease it.



For private listening

Connect a pair of headphones to the PHONES jack. No sound comes out of the speakers. Be sure to turn down the volume before connecting or putting on headphones.



Always set the volume to the minimum before starting any source. If the volume is set to extremely high level, a sudden blast of sound can damage your hearing, speakers and/or headphones.

- If you have turned off (on standby) the unit with the volume level set at more than level "15," the volume level will be automatically set at level "15" next time you turn on the unit.

To turn down the volume level temporarily

Press **FADE MUTING** on the remote control.

The volume level gradually decreases to "VOL MIN."

To restore the sound, press the button again.




Reinforcing the Bass Sound

This function only affects the playback sound, not your recording.


Press down the **SUBWOOFER LEVEL** +/– control to increase the subwoofer sound or up the control to decrease it.

- The subwoofer level can be adjusted in 3 steps (LEVEL 1 — LEVEL 3).

If you press down the control to increase the level beyond LEVEL 3, "MAX LEVEL" appears on the display.



WOOFER indicator also shows the current subwoofer level.



When using the remote control, press **SUBWOOFER LEVEL +** to increase the subwoofer sound or press **SUBWOOFER LEVEL -** to decrease it.

Enjoying the Powerful Sound—RHYTHM AX

Using **RHYTHM AX**, harder-hitting beats intensify your listening experience even at low sound levels.


RHYTHM AX also works even when the song has no "beat," such as classical music, so that you can listen to the rich sound even at low sound levels.

This function only affects the playback sound, not your recording.

Press down the **RHYTHM AX** control.


"**RHYTHM AX**" (twice), then "**ON**" appears on the display.

- Each time you press down the control, **RHYTHM AX** turns on and off alternately.
- The **RHYTHM AX** lamp also lights up.



When using the remote control, press **RHYTHM AX**.

- Each time you press the button, **RHYTHM AX** turns on and off alternately.





Selecting the Sound Modes

This function only affects the playback sound, not your recording.

You can select one of the 6 preset sound modes (3 surround modes and 3 SEA—Sound Effect Amplifier—modes).

To select the sound modes, press up the SOUND MODE control repeatedly until the sound mode you want appears on the display.


- The SOUND MODE lamp also lights up.



SOUND MODE indicator also lights up on the display

- First time you press up the control, the current sound mode appears on the display.

Each time you press up the control while a sound mode appears on the display, the sound modes change as follows:



Surround modes*:

D.CLUB : Increases resonance and bass.

HALL : Adds depth and brilliance to the sound.

STADIUM: Adds clarity and spreads the sound, like in an outdoor stadium.

SEA (Sound Effect Amplifier) modes:


ROCK : Boosts low and high frequency. Good for acoustic music.


POP : Good for vocal music.

CLASSIC : Good for classical music.

OFF : Cancels the sound mode.

* Surround elements are added to the SEA elements to create being-there feeling in your room.


When one of these modes is selected, the SOUND MODE indicator lights up as .

While one of the SEA modes (SEA elements without surround elements) is selected, the SOUND MODE indicator lights up as .

When using the remote control, press SOUND MODE to select the sound mode.

- First time you press the button, the current sound mode appears on the display.

Each time you press the button while a sound mode appears on the display, the sound modes change as follows:



Turning On or Off the Key-touch Tone

If you do not want the key-touch tone to beep each time you press a button or turn a control, you can deactivate it.

- You can turn on or off the key-touch tone as follows:

–When the unit is off:


You can turn on or off the key-touch tone by operating the unit.

–When the unit is on:

You can turn on or off the key-touch tone by operating the unit or the remote control.

On the unit:

Press and hold BEEP for more than 2 seconds.



- Each time you press and hold the button, the key-touch tone turns on and off alternately.

On the remote control:

Press BEEP ON/OFF when the unit is on.

- Each time you press the button, the key-touch tone turns on and off alternately.



Listening to the Radio



Tuning in to a Station—Auto Search

1 Press FM/AM.

The unit automatically turns on and tunes in to the previously tuned station (either FM or AM—MW).


- Each time you press the button, the band alternates between FM and AM (MW).



2 Start searching for stations.


On the unit:

Press and hold TUNING + or TUNING – for more than 1 second.



On the remote control:

Press and hold ►►/►► or ◀◀/◀◀ for more than 1 second.



The unit starts searching for stations and stops when a station of sufficient signal strength is tuned in to. If a program is broadcast in stereo, the ST (stereo) indicator lights up.

To stop during searching, press TUNING + or TUNING – (or ►►/►► or ◀◀/◀◀ on the remote control).



When you press TUNING + or TUNING – (or ►►/►► or ◀◀/◀◀ on the remote control) briefly and repeatedly

The frequency changes step by step.

To change the FM reception mode

When an FM stereo broadcast is hard to receive or noisy, press FM MODE on the remote control so that “MONO” appears and the MONO indicator also lights up on the display. Reception improves.



To restore the stereo effect, press FM MODE again so that “STEREO” appears on the display.

In this stereo mode, you can hear stereo sounds when a program is broadcast in stereo.

Presetting Stations

You can preset 30 FM and 15 AM (MW) stations.

In some cases, test frequencies have been already memorized for the tuner since the factory examined the tuner preset function before shipment. This is not a malfunction. You can preset the stations you want into memory by following the presetting method.

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 2 again.


On the unit ONLY:

1 Tune in to the station you want to preset (in this example, of FM 87.50).


- See “Tuning in to a Station—Auto Search.”

FM 87.50


2 Press SET/DISPLAY.



3 Press PRESET + or PRESET – to select a preset number.



4 Press SET/DISPLAY again.



STORED

The tuned station in step 1 is stored in the preset number selected in step 3.

- Storing a new station on a used number erases the previously stored one.



When you unplug the AC power cord or if a power failure occurs

The preset stations will be erased in a few days. If this happens, preset the stations again.

Tuning in to a Preset Station

1 Press FM/AM.


- See “Tuning in to a Station—Auto Search,” step 1 for details.



2 Select a preset number.

On the unit:

Press PRESET + or PRESET –.



On the remote control:

Press the number buttons.

Ex.: For preset number 5, press 5.

For preset number 15,


press +10 then 5.

For preset number 20,

press +10, then 10.

For preset number 25, press +10, +10, then 5.

For preset number 30, press +10, +10, then 10.



Receiving FM Stations with RDS

RDS (Radio Data System) allows FM stations to send an additional signal along with their regular program signals. For example, the stations send their station names, as well as information about what type of program they broadcast, such as sports or music, etc.

When tuned in to an FM station which provides the RDS service, the RDS indicator lights up on the display.

With the unit, you can receive the following types of RDS signals.

PS (Program Service):

Shows commonly known station names.

RT (Radio Text):

Shows text messages the station sends.

CT (Clock Time):

Shows clock time the station sends.

PTY (Program Type):

Shows types of broadcast programs.

Enhanced Other Networks:

Provides the information about the types of the programs sent by other RDS stations.



More about RDS

- Some FM stations do not provide RDS signals.
- RDS services may vary among FM RDS stations. For details on RDS services in your area, check with local radio stations.
- RDS may not work correctly if the received station is not transmitting the signals properly or if the signal strength is weak.


Changing the RDS Information

You can see RDS information on the display while listening to an FM station.

On the remote control ONLY:

Press DISPLAY MODE.

- Each time you press the button, the display changes as follows:



About characters shown on the display

When the display shows PS name, RT or CT signals:

- The display cannot differentiate upper case and lower case letters and always uses upper case letters.
- Some special characters and marks may not be displayed correctly.



If no PS name, RT, or CT signals are sent by a station

“NO PS,” “NO RT,” or “NO CT” appears on the display.

Searching for Programs by PTY Codes (PTY Search)

One of the advantages of RDS is that you can locate a particular kind of program by specifying PTY codes.

- For details on the PTY codes, see “Additional Information” on page 30.

To search for a program using PTY codes


- PTY Search is applicable only to preset FM RDS stations. If not yet done, see “Presetting Stations” on page 12.
- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

On the remote control ONLY:

- 1 Press RDS MODE while listening to an FM station.



- 2 Press SELECT + or SELECT - until the PTY code you want appears on the display.



NEWS

- Each time you press the button, PTY codes change as follows:

NEWS ⇄ AFFAIRS ⇄ INFO ⇄ SPORT ⇄
EDUCATE ⇄ DRAMA ⇄ CULTURE ⇄
SCIENCE ⇄ VARIED ⇄ POP M ⇄ ROCK M ⇄
M.O.R.M ⇄ LIGHT M ⇄ CLASSICS ⇄
OTHER M ⇄ WEATHER ⇄ FINANCE ⇄
CHILDREN ⇄ SOCIAL ⇄ RELIGION ⇄
PHONE IN ⇄ TRAVEL ⇄ LEISURE ⇄ JAZZ ⇄
COUNTRY ⇄ NATION M ⇄ OLDIES ⇄
FOLK M ⇄ DOCUMENT ⇄ (back to the beginning)

- 3 Press RDS MODE again while the PTY code selected in the previous step is still on the display.



The preset FM stations appear on the display with their preset numbers.

The unit searches 30 preset FM stations, stops when it finds the one you have selected and tunes in to that station.


- If no program is found, the unit returns to the last received station.

To stop during searching

Press SELECT + or SELECT -.

To check the PTY, press RDS MODE once so that the current PTY code appears.

- “NO PTY” appears if no signal is sent.



Switching Temporarily to a Program Type of Your Choice

The Enhanced Other Networks function allows the unit to switch temporarily to a broadcast program of your choice (NEWS or INFO) from a different station.

To activate the Enhanced Other Networks function

Enhanced Other Networks function is applicable only to preset FM RDS stations. If not yet done, see “Presetting Stations” on page 12.

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

On the remote control ONLY:



1 Press and hold RDS MODE for more than 1 second.

“E. SELECT” appears on the display.



2 Press SELECT + or SELECT – to select the data type.

- Each time you press the button, the data type of the Enhanced Other Networks changes as follows:



NEWS: News

INFO: Program the purpose of which is to impart advice in the widest sense.

E. OFF: The function is canceled.

The data type indicator (NEWS or INFO) you have selected also lights up on the display.

Now, the function is activated. See “How the Enhanced Other Networks function actually works.”

To cancel the function, repeat from step 1 and select “E. OFF” in step 2.

The data type indicator (NEWS or INFO) goes off.

How the Enhanced Other Networks function actually works:

CASE 1

If there is no station broadcasting the program you have selected

The unit continues tuning in to the current station.



When a station starts broadcasting the program you have selected, the unit automatically switches to the station. The selected data type indicator starts flashing on the display.



When the program is over, the unit goes back to the previously tuned station, but the Enhanced Other Networks function still remains activated.

CASE 2

If there is a station broadcasting the program you have selected

The unit tunes in to the program. The selected data type indicator starts flashing.



When the program is over, the unit goes back to the previously tuned station, but the Enhanced Other Networks function still remains activated.

CASE 3

If the FM station you are listening to is broadcasting the program you have selected

The unit continues to receive the station but the selected data type indicator starts flashing.



When the program is over, the indicator stops flashing, but the Enhanced Other Networks function still remains activated.



More about the Enhanced Other Networks function

- Enhanced Other Networks data sent from some stations may not be compatible with this unit. In this case, the Enhanced Other Networks function may not work correctly.
- While listening to a program tuned in by this function, the station does not change even if another network station starts broadcasting a program of the same Enhanced Other Networks data.
- If the stations alternate intermittently between the station tuned by this function and the currently tuned station, cancel this function by following the procedure in the left column.
- The Enhanced Other Networks function is canceled when you change the source to CD, TAPE or AUX.
- The Enhanced Other Networks function is temporarily canceled when you change the band to AM (MW).

Playing Back CDs

This unit has been designed to playback the following CDs:

- Audio CD
- CD-R (CD-Recordable)
- CD-RW (CD-ReWritable)
- MP3 disc (MP3 files recorded on a CD-R or CD-RW)*

When playing a CD-R or CD-RW

- User-edited CD-Rs (CD-Recordable) and CD-RWs (CD-ReWritable) can be played back when they are already “finalized.”
- Before playing back CD-Rs or CD-RWs, read their instructions or cautions carefully.
- Some CD-Rs or CD-RWs may not be played back on this unit because of their disc characteristics, damage or stain on them, or if the player’s lens is dirty.

Important notices:

- In general, you will have the best performance by keeping your CDs and the mechanism clean.
 - Store CDs in their cases, and keep them in cabinets or on shelves.
 - Keep the unit’s carrousel closed when not in use.
- Continuous use of irregular shaped discs (heart-shape, octagonal, etc.) can damage the disc rotating mechanism.



- CD-RWs may require a longer readout time since the reflectance of CD-RWs is lower than for regular CDs.

*For MP3 discs

- This unit manages files and folders on MP3 discs as “tracks” and “albums.”
- Playback order of the MP3 files (tracks) recorded on a disc are determined by the writing (or encoding) application; therefore, playback order may be different from the one you have intended while recording the files and the folders.
- This unit shows the file (track) names and the ID3v1/1.1 tags (only “Title” and “Artist”) on the display after the file starts play; however, there is a limitation on available characters and some file names and ID3v1/1.1 tags are not shown correctly.




More about MP3 discs

- MP3 discs (either CD-R or CD-RW) require a longer readout time. (It varies due to the complexity of the recording configuration.)
- When making an MP3 disc, select ISO 9660 Level 1 or Level 2 as the disc format.
- This unit does not support multisession recording.
- This unit can play MP3 files only with the following file extensions—“.MP3,” “.Mp3,” “.mp3,” and “.mp3.”
- Non-MP3 files are ignored. If non-MP3 files are recorded together with MP3 files, this unit will take a longer time to scan the disc. It may also cause the unit to malfunction.
- Some MP3 discs may not be played back because of their disc characteristics or recording conditions.


Loading CDs

1 Press CD ▲.

The unit automatically turns on and the carrousel comes out.



2 Place one or two discs correctly on the front recesses of the disc tray, with its label side up.



- When using a CD single (8 cm), place it on the inner recess of the disc tray.

3 If you wish to load a third disc, press DISC CHANGE on the unit or DISC SKIP on the remote control.

The disc tray rotates by 120°.



4 Press CD ▲ again.

The carrousel closes.



Playing Back CDs—All Disc and One Disc

You can play all loaded CDs continuously—All Disc play, or one selected disc—One Disc play.


All Disc play

On the unit ONLY:


1 Load CDs.

- If the current playing source is not the CD player, press CD ►/II, then ■ before going to the next step.


2 Press REPEAT repeatedly so that the ALL DISC indicator lights up on the display.



For Audio CD:




For MP3 disc:



GROUP indicator appears when the MP3 playback mode is the ALBUM mode. See also page 19.

- Each time you press the button, the indication on the display changes as follows:




* See page 21.

3 Press one of the disc number buttons (CD1, CD2 or CD3) for the disc you want to start to play from.


CD play starts from the first track of the selected disc.

- Pressing CD ►/II instead of the disc number buttons starts playing back if a CD is on the tray.



For Audio CD:

Track number of the currently playing disc flashes (Track numbers exceeding 16 are not displayed.)




For MP3 disc:

- When the MP3 playback mode is the **ALBUM** mode (See also page 19.)

Current album number



Current track title scrolls.




When the track includes the ID3v1/1.1 tags, "Title" and "Artist" will scroll after the track title.

- "<TITLE>" appears before the content of "Title" scrolls and "<ARTIST>" appears before the content of "Artist" scrolls.


Current track number of the current album

Elapsed playing time



- When the MP3 playback mode is the **TRACK** mode (See also page 19.)


Current track title scrolls.



When the track includes the ID3v1/1.1 tags, "Title" and "Artist" will scroll after the track title.

- "<TITLE>" appears before the content of "Title" scrolls and "<ARTIST>" appears before the content of "Artist" scrolls.

Current track number** Elapsed playing time



** In the TRACK mode, the unit manages only files (tracks) on the MP3 disc. Folders (albums) are not recognized.

To stop during play, press ■.

- For MP3 disc, this unit can store the number of the track that you have stopped playback. By pressing CD ►/II, you can start playback again from the beginning of the same track—Resume play (see also page 19).

To remove the disc, press CD ▲.



CD playback sequence

When 3 CDs are loaded on the disc trays, they are played in one of the following sequences.

- When CD1 is pressed : CD1 ⇒ CD2 ⇒ CD3 (then stops)
- When CD2 is pressed : CD2 ⇒ CD3 ⇒ CD1 (then stops)
- When CD3 is pressed : CD3 ⇒ CD1 ⇒ CD2 (then stops)

* When only 2 CDs are loaded, they are played in the same order, but the disc tray without a CD is skipped.



About the CD READY lamps (CD1, CD2, and CD3)

- Each lamp corresponds to the disc tray of the same number.
- The CD READY lamp flashes while the corresponding CD is being played.
- The CD READY lamp goes off when the unit has detected that there is no CD on the corresponding disc tray.

One Disc play

When 2 or 3 CDs are loaded on the disc trays, you can select one particular disc to be played back.

On the unit ONLY:


1 Load CDs.

- If the current playing source is not the CD player, press CD ►/||, then ■ before going to the next step.

2 Press REPEAT repeatedly so that the 1 DISC indicator lights up on the display.




- Each time you press the button, the indication on the display changes as follows:



* See page 21.

3 Press one of the disc number buttons (CD1, CD2 or CD3) you want to listen.



Playback stops when all tracks of the selected disc are played once and resumes to All Disc play.

To stop during play, press ■.

- For MP3 disc, this unit can store the number of the track that you have stopped playback. By pressing CD ►/||, you can start playback again from the beginning of the same track—Resume play (see also page 19).

To remove the disc, press CD ▲.

To exit from One Disc play, press REPEAT repeatedly so that ALL DISC indicator lights up on the display.



The following operations will also cancel the One Disc play and restore All Disc play when—

- Stopping playback,
- Turning off the power,
- Ejecting the carrousel, or
- Changing the source to play.

Basic CD Operations

While playing a CD, you can do the following operations.

To exchange CDs during playback of another

Press DISC CHANGE to change the CD and the carrousel comes out.

If you change CDs during play, the current play will not stop until all CDs you have changed are played.



To close the carrousel, press DISC CHANGE or CD ▲.

To skip to another CD in the carrousel

Press DISC SKIP on the remote control.



To stop play for a moment

Press CD ►/||.

While pausing, “PAUSE” appears on the display.

To resume play, press CD ►/|| again.




To locate a particular point in a track

During play, press and hold ►► or ◀◀.

►►: Fast forwards the disc.

◀◀: Fast reverses the disc.



When using the remote control, press and hold ►►/►► or ◀◀/◀◀.




To go to another track

For Audio CD:


Press ►►| or ◀◀ before or during playback.

►►|: Skips to the beginning of the next or succeeding tracks.

◀◀: Goes back to the beginning of the current or previous tracks.



When using the remote control, press ►►|/►► or ◀◀/◀◀.



If you press ►►| or ◀◀ (or ►►|/►► or ◀◀/◀◀ on the remote control) to select a track while playback is stopped


The selected track starts playback.

For MP3 disc:**When the MP3 playback mode is the TRACK mode**


(See also page 19.)

Press ►► or ◀◀ before or during playback.

- ►►: Skips to the beginning of the next or succeeding tracks.
- ◀◀: Goes back to the beginning of the current or previous tracks.



When using the remote control, press ►►/►► or ◀◀/◀◀.



If you press ►► or ◀◀ (or ►►/►► or ◀◀/◀◀ on the remote control) to select a track while playback is stopped


The selected track starts playback.

To go to another album on an MP3 disc**When the MP3 playback mode is the ALBUM mode**

(See also page 19.)

Press ►► or ◀◀ before or during playback.

- ►►: Skips to the beginning of the first track in the next or succeeding albums.
- ◀◀: Goes back to the beginning of the first track in the previous albums.



When using the remote control, press ►►/►► or ◀◀/◀◀.




If you press ►► or ◀◀ (or ►►/►► or ◀◀/◀◀ on the remote control) to select an album while playback is stopped

The first track in the selected album starts playback.

To go to another track directly using the number buttons**For Audio CD:**

Pressing the number button(s) before or during play allows you to start playing the selected track.



Ex.: For track number 5, press 5.

For track number 15, press +10, then 5.


For track number 20, press +10, then 10.

For track number 32, press +10, +10, +10, then 2.

For MP3 disc:**• When the MP3 playback mode is the TRACK mode**

(See also page 19.)

Pressing the number button(s) before or during play allows you to start playing the selected track on the disc.



Ex.: For track number 5, press 5.

For track number 15, press +10, then 5.

For track number 20, press +10, then 10.


For track number 32, press +10, +10, +10, then 2.

For track number 123, press +10 twelve times, then 3.

• When the MP3 playback mode is the ALBUM mode

(See also page 19.)

Pressing the number button(s) before or during play allows you to start playing the selected track in the current album.



Ex.: For the 5th track in the current album, press 5.

For the 15th track in the current album, press +10, then 5.

For the 20th track in the current album, press +10, then 10.

For the 32nd track in the current album, press +10, +10, +10, then 2.

For the 123rd track in the current album, press +10 twelve times, then 3.

**If your entry is ignored**

You have tried to enter a track number that does not exist on the disc or in the album (for example, selecting track 14 in the album that only has 12 tracks). Such entries are ignored.

Changing the MP3 Playback Mode

When playing an MP3 disc, you can choose the playback mode of the MP3 disc as follows:

- **TRACK mode:**

The unit recognizes only tracks (files). You can play an MP3 disc like an Audio CD.

- **ALBUM mode:**

The unit recognizes tracks (files) and albums (folders) on an MP3 disc. You can play an MP3 disc according to the way how they are grouped.

In this mode, you can do the following operations:

- Pressing ►►► or ◀◀◀ (or ►►►/►►► or ◀◀◀/◀◀◀ on the remote control) allows you to skip to the first track of the previous or next albums. (See page 18.)
- Pressing the number button(s) allows you to start playing the selected track in the current album. (See page 18.)

On the remote control ONLY:

Press **MP3** before or during playing an MP3 disc.



GROUP indicator appears when the MP3 playback mode is the ALBUM mode.

- Each time you press the button, the MP3 playback mode changes between “ALBUM” and “TRACK” alternately.

Turning On or Off the Resume Play for MP3 Disc

For MP3 disc, this unit can store the number of the track that you have stopped playback. By pressing CD ►/||, you can start playback again from the beginning of the same track—Resume play.

You can turning on and off the resume play for MP3 discs.

On the unit ONLY:

Press **PROGRAM** before or during playing an MP3 disc.



- Each time you press PROGRAM, the resume play turns on and off alternately.



If you unplug the AC power cord

The resume play is back to on.



The following operations will erase the memory of the track number that you have stopped playback when—

- Pressing CD ▲ to eject the disc.
- Pressing one of the disc number buttons (or DISC SKIP on the remote control) to change the disc to play.

Programming the Playing Order of the Tracks —Program Play

You can arrange the order in which the tracks play before you start playing. **You can program up to 32 tracks.**

- To use Repeat play (see page 21) for Program play, press REPEAT after starting Program play.



Playback and recording for Program play are not available to MP3 discs on this unit

There may be a malfunction in case that you try to do such playback or recording.

If a malfunction occurs, unplug the AC power cord and then plug it back in.

On the unit ONLY:

1 Load CDs.

- If the current playing source is not the CD player, press CD ►/II, then ■ before going to the next step.

2 Press PROGRAM so that “PROGRAM” appears on the display.




The PRGM (program) indicator also lights up on the display.

- All Disc play is selected automatically. You cannot select One Disc play for Program play.




- If a program has been stored in memory, the program is called up.

3 Press one of the disc number buttons (CD1, CD2, and CD3) to select the disc number you want to play.




Disc number Program step number



4 Press ►► or ◀◀ to select the track number, then press SET/DISPLAY.

Each time you select a track and press SET/DISPLAY, the selected track number is added to the track number indicator.

- You can select up to the 99th track on each disc.



5 Program other tracks you want.

- To program tracks from the same disc, repeat step 4.
- To program tracks from a different disc, repeat steps 3 and 4.

6 Press CD ►/II.

The tracks are played in the order you have programmed.




To stop during play, press ■.

To exit from Program play, press PROGRAM again before or after play so that the unit enters All Disc play. (The program you have made is stored in memory until you turn off the unit, eject the carrousel, or erase the program.)

- Program play is also canceled when you press CD ▲.

To modify the program

Before playing, you can erase the last programmed track shown on the display by pressing CANCEL/DEMO.



- Each time you press the button, the last programmed track is erased from the program.

To add tracks in the program before play, simply select the disc numbers and/or track numbers you want to add by following steps 3 and 4 of the programming procedure.

To check the program before play, perform the following procedure:

1 Press RANDOM while Program play is stopped.

2 Press ►► or ◀◀.

The programmed tracks appear on the display in the programmed (or reverse) order.

- Pressing CD ►/II starts Program play from the first track of the program.



If you want to add tracks in the program after checking the program

Press PROGRAM twice, then add tracks by following steps 3 and 4 of the programming procedure.

To erase the entire program, press ■ while Program play is stopped.

- Turning the power off or ejecting the carrousel will also erase the stored memory.



If you try to add another track when 32 tracks are already programmed

“FULL” appears on the display and the 32nd track is replaced by the newly added track.



If you have programmed a track from an empty tray, or a track number that does not exist on the disc

Such program steps will be skipped.



Playing at Random—Random Play


The tracks of the selected CD will play at random.

- To use Random play, you have to cancel Program play.

On the unit ONLY:

1 Load a CD.

2 Press one of the disc number buttons (CD1, CD2, and CD3) for the disc you want to play, then press ■.



3 Press RANDOM so that “RANDOM” appears on the display.

The RANDOM indicator also lights up on the display.

- Activating Random play cancels Repeat play or All Disc play. (One Disc play is automatically selected.)
- For MP3 discs, activating Random play changes the ALBUM mode to the TRACK mode.



- The tracks are played automatically at random. Random play ends when all tracks are played once.

To stop and cancel Random play, press ■.

- If you press RANDOM again during play, Random play is canceled and the unit enters All Disc play mode.
- Random play is also canceled when you press CD ▲.



If you press ►► or ◀◀ (or ►►/►► or ◀◀/◀◀ on the remote control)

Playback skips to the next track selected randomly.

Repeating Tracks or CDs—Repeat Play

You can have all the CDs, the program or the individual track currently playing repeat as many times as you like.

- Repeat play and Random play cannot be used at the same time.

On the unit ONLY:

To repeat play, press REPEAT during or before playing.



- Each time you press the button, Repeat play mode changes as follows, and the following indicator lights up on the display:



REPEAT 1:

Repeats one track on one CD.

REPEAT 1 DISC:**

Repeats all the tracks on one CD.

REPEAT ALL DISC:

Repeats all the tracks on all the CDs, or all the tracks on the program.

* See pages 15 and 17.

** REPEAT 1 DISC is not used for Program play.

To cancel Repeat play, press REPEAT repeatedly until the REPEAT indicator (REPEAT 1, REPEAT 1 DISC or REPEAT ALL DISC) goes off from the display.

- Repeat play is also canceled in the following cases:
 - When you press ■ or CD ▲.
 - When you change the source.
 - When you turn off the unit.

Prohibiting Disc Ejection—Carrousel Lock

You can prohibit CD ejection from the unit and can lock the carrousel.

- This operation is possible only while the unit is on with CD selected as the source.

On the unit ONLY:

To prohibit disc ejection, press CD ▲ for the carrousel while holding ■.

“LOCKED” appears for a while, and the carrousel is locked.



If you try to eject CDs

“LOCKED” appears to inform you that the Carrousel Lock is in use.

To cancel the prohibition and unlock the carrousel, press CD ▲ for the carrousel while holding ■.

“UN LOCKED” appears for a while, and the carrousel is unlocked.



When you unplug the AC power cord or if a power failure occurs


The setting of the Carrousel Lock will return to the initial setting (not to prohibit disc ejection) in a few days.

Playing Back Tapes




Playing Back a Tape

1 Press **▲** for the deck you want to use.



2 Put a cassette in, with the exposed part of the tape down and the side you want to play facing front.


- You can play back only type I tapes.



3 Close the cassette holder gently.

4 Press **TAPE A ▶** for the deck A or **TAPE B ▶** for the deck B.

The tape play starts and the tape running indicator (▶) starts flashing slowly.



The operating deck (A or B) indicator shows the deck currently selected.

When the tape plays to the end, the deck automatically stops.

To stop during play, press **■**.

To fast-forward the tape, press **▶▶** (or **▶▶/▶▶** on the remote control). The tape running indicator (▶) starts flashing quickly.



To rewind the tape, press **◀◀** (or **◀◀/◀◀** on the remote control). The tape running indicator (▶) starts flashing quickly.



When you fast-forward or rewind the tape while the tape play is stopped

You can fast-forward or rewind the tape in the deck currently selected.

To remove the cassette, press **▲** for deck A or B.



The use of the C-120 or thinner tape is not recommended, since characteristic deterioration may occur and this tape easily jams in the pinch-rollers and the capstans.

Recording

IMPORTANT:


- It should be noted that it may be unlawful to re-record pre-recorded tapes, records, or discs without the consent of the owner of copyright in the sound or video recording, broadcast or cable program and in any literary, dramatic, musical, or artistic embodied therein.
- The recording level is automatically set correctly, so it is not affected by the VOLUME, the SUBWOOFER LEVEL, the RHYTHM AX, and the SOUND MODE controls. Thus, during recording you can adjust the sound you are actually listening to without affecting the recording level.
- If recordings you have made have excessive noise or static, the unit may be too close to a TV. Place the unit away from the TV.
- You can use type I tape for recording.

To protect your recording

Cassettes have two small tabs on the back to protect unexpected erasure or re-recording.

To protect your recording, remove these tabs.

To re-record on a protected tape, cover the holes with adhesive tape.




To keep the best recording and playback sound quality

If the heads, capstans, and pinch rollers of the cassette decks become dirty, the following will occur:

- Impaired sound quality
- Discontinuous sound
- Fading
- Incomplete erasure
- Difficulty in recording

To clean the head, capstan, and pinch roller

Use a cotton swab moistened with alcohol.




To demagnetize the head

Turn off the unit, and use a head demagnetizer (available at electronics and audio shops).

Recording a Tape on Deck B

On the unit ONLY:

1 Press **▲** for deck B.



2 Put a recordable cassette in, with the exposed part of the tape down and the side you want to record facing front.

3 Close the cassette holder gently.

4 Start playing the source—FM, AM (MW), CD player or auxiliary equipment connected to AUX IN jack.

- For duplicating tapes, see “Dubbing Tapes” on page 24.
- For recording from CD, see “CD Synchronized Recording” on page 24.

5 Press **REC START/STOP**.


The REC (recording) indicator lights up on the display and recording starts.

- The REC (recording) lamp also lights up during recording.



To stop during recording, press REC START/STOP again or **■**.


To remove the cassette, press **▲** for deck B.



Dubbing Tapes

On the unit ONLY:

1 Press TAPE A ►, then ■.



2 Put the source cassette in deck A, and a recordable cassette into deck B.

3 Press DUBBING.

Dubbing starts.

“DUBBING” appears, and the REC (recording) indicator lights up on the display.

- The REC (recording) lamp also lights up during recording.



To stop during dubbing, press REC START/STOP or ■.

To remove the cassettes, press ▲ for deck A and B.

CD Synchronized Recording

You can easily record a CD onto a tape.

- This function does not work for MP3 discs. When recording an MP3 disc onto a tape, see “Recording a Tape on Deck B” on page 23.
- You can also record the tracks in the order you have made the program.



notes Playback and recording for Program play are not available to MP3 discs on this unit

There may be a malfunction in case that you try to do such playback or recording.


If a malfunction occurs, unplug the AC power cord and then plug it back in.

On the unit ONLY:

1 Put a recordable cassette into deck B.

2 Place a disc correctly on the recess of the disc tray, with its label side up.

3 Press one of the disc number buttons (CD1, CD2, and CD3) to select the disc, then ■.



4 Press CD REC START.

“CD REC” appears, and the REC (recording) indicator lights up on the display.

- The REC (recording) lamp also lights up during recording.



Deck B starts recording and the CD player starts playing. When the recording from the selected CD is done, the CD player and deck B stop.

- When recording your program, the CD player and deck B stop after all tracks in the program are recorded.

To stop during CD Synchronized Recording, press REC START/STOP or ■.

To remove the cassette, press ▲ for deck B.

Using the Timers


There are three timers available—Daily Timer, Recording Timer, and Sleep Timer.

Before using the timers, you need to set the clock built in the unit. (See “Setting the Clock” on page 9.)

Using Daily Timer

With Daily Timer, you can wake to your favorite music or radio program. You can set the timer whether the unit is on or off.

How Daily Timer actually works

The unit automatically turns on, set the volume level to the preset level, and starts playing the specified source when the on-time comes (the  indicator flashes while the timer is operating). Then, when the off-time comes, the unit automatically turns off (stands by).

Daily Timer works every day unless you cancel it.


- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step **1** again.
- If you have made a mistake while setting timer, press CANCEL/DEMO. (However, this does not always work. If CANCEL/DEMO does not work, press CLOCK/TIMER repeatedly and start from step **1** again.)


Before you start...

- *When using the tuner as the source to play:*
— Make sure to preset a station you want to play. (See page 12.)
- *When using a CD as the source to play:*
— Make sure there is a CD you want to play on the currently selected disc number tray.
- *When using a tape as the source to play:*
— Make sure that a tape you want to play is in the deck A if there are tapes in both the deck A and B.
- *When using the external component as the source to play:*
— Set the timer equipped with the external component at the same time.

On the unit ONLY:

- 1 Press CLOCK/TIMER repeatedly until “DAILY” appears on the display.**



 indicator lights up and the DAILY (daily timer) indicator starts flashing on the display.





- Each time you press the button, the clock/timer setting modes change as follows:








- 2 Press CLOCK/TIMER again.**

“ON TIME” appears for 2 seconds, then the unit enters on-time setting mode.









- 3 Set the on-time you want the unit to turn on.**

- 1) Press  or  to set the hour, then press SET/DISPLAY.
- 2) Press  or  to set the minute, then press SET/DISPLAY. “OFF TIME” appears for 2 seconds, then the unit enters off-time setting mode.



- 4 Set the off-time you want the unit to turn off (on standby).**

- 1) Press  or  to set the hour, then press SET/DISPLAY.
- 2) Press  or  to set the minute, then press SET/DISPLAY. The unit enters source selecting mode.



5 Press ►► or ◀◀ to select the source to play, then press SET/DISPLAY.

- Each time you press ►► or ◀◀, the source changes as follows:



TUNER FM : tunes in to a specified preset FM station.

→ go to step 6.

TUNER AM : tunes in to a specified preset AM (MW) station.

→ go to step 6.

CD : plays the current disc from the first track.

→ go to step 7.

TAPE : plays a tape in deck A or B.

→ go to step 7.


AUX : plays an external source.

→ go to step 7.

6 Select the preset station number.



Press ►► or ◀◀ to select the preset station number, then press SET/DISPLAY.

The unit enters volume setting mode.




7 Press ►► or ◀◀ to set the volume level.

- You can select the volume level from VOL MIN, VOL 1 — VOL 30, and VOL MAX.




8 Press SET/DISPLAY to complete the Daily Timer setting.

The DAILY (daily timer) indicator stops flashing and remains lit. The settings you have done are shown on the display in sequence for your confirmation.




9 Press ◻/I STANDBY/ON to turn off the unit (on standby) if you have set the Daily Timer with the unit turned on.




To turn on or off Daily Timer after its setting is done

1 Press CLOCK/TIMER repeatedly until "DAILY" appears on the display.




2 To turn off the Daily Timer, press CANCEL/DEMO.



The DAILY (daily timer) indicator goes off from the display ("OFF" appears for a while).

The Daily Timer is canceled, but the setting for the Daily Timer remains in memory until you change it.

To turn on the Daily Timer, press SET/DISPLAY.



The DAILY (daily timer) indicator lights up on the display. The settings you have done are shown on the display in sequence for your confirmation.




If the unit is turned on when the timer-on time comes Daily Timer does not work.

Using Recording Timer

With Recording Timer, you can make a tape of a radio broadcast automatically. You can set the timer whether the unit is on or off.

How Recording Timer actually works

The unit automatically turns on, tunes in to the specified station, sets the volume level to “VOL MIN,” and starts recording when the on-time comes (the  indicator flashes while the timer is operating). Then, when the off-time comes, the unit automatically turns off (stands by).

Recording Timer works only once, but the timer setting remains in memory until you change it.

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 2 again.
- If you have made a mistake while setting the timer, press CANCEL/DEMO. (However, this does not always work. If CANCEL/DEMO does not work, press CLOCK/TIMER repeatedly and start from step 2 again.)


Before you start...


Make sure to preset a station you want to record. (See page 12.)

On the unit ONLY:

1 Put a recordable cassette into deck B.

2 Press CLOCK/TIMER repeatedly until “REC” appears on the display.

 indicator lights up and the REC (recording timer) indicator starts flashing on the display.





- Each time you press the button, the clock/timer setting modes change as follows:








3 Press CLOCK/TIMER again.

“ON TIME” appears for 2 seconds, then the unit enters on-time setting mode.








4 Set the on-time you want the unit to turn on.

- 1) Press  or  to set the hour, then press SET/DISPLAY.
 - 2) Press  or  to set the minute, then press SET/DISPLAY.
- “OFF TIME” appears for 2 seconds, then the unit enters off-time setting mode.








5 Set the off-time you want the unit to turn off (on standby).

- 1) Press  or  to set the hour, then press SET/DISPLAY.
 - 2) Press  or  to set the minute, then press SET/DISPLAY.
- The unit enters preset station selecting mode.




6 Select the preset station.

- 1) Press  or  to select the band (“TUNER FM” or “TUNER AM”), then press SET/DISPLAY.
 - 2) Press  or  to select a preset channel number, then press SET/DISPLAY.
- The REC (recording timer) indicator stops flashing and remains lit. The settings you have done are shown on the display in sequence for your confirmation.



7 Press /STANDBY/ON to turn off the unit (on standby) if necessary.



About the recording source

If you change the source while recording, the recording source also changes.

Maintenance



To get the best performance of the unit, keep your discs, tapes, and mechanism clean.

Cleaning the unit



• Stains on the unit

Should be wiped off with a soft cloth. If the unit is heavily stained, wipe it with a cloth soaked in water-diluted neutral detergent and wrung well, then wipe clean with a dry cloth.

• Avoid the following since they may cause damage to the unit.

- DO NOT wipe it with a hard cloth.
- DO NOT wipe it strong.
- DO NOT wipe it with thinner or benzine.
- DO NOT apply any volatile substance such as insecticides to it.
- DO NOT allow any rubber or plastic to remain in contact with it for a long time.

Handling discs



- Remove the disc from its case by holding it at the edge while pressing the center hole lightly.
- Do not touch the shiny surface of the disc, or bend the disc.
- Put the disc back in its case after use to prevent warping.
- Be careful not to scratch the surface of the disc when placing it back in its case.
- Avoid exposure to direct sunlight, temperature extremes, and moisture.


To clean the disc

Wipe the disc with a soft cloth in a straight line from center to edge.



DO NOT use any solvent—such as conventional record cleaner, spray, thinner, or benzine—to clean the disc.

Handling cassette tapes



- If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.
- If the tape is loose, it may get stretched, cut, or caught in the cassette.
- Be careful not to touch the tape surface.
- Avoid the following places to store the tape:
 - In dusty places
 - In direct sunlight or heat
 - In moist areas
 - Near a magnet

Additional Information




Description of the PTY codes:

NEWS:	News.	WEATHER:	Weather reports and forecasts.
AFFAIRS:	Topical program expanding or enlarging upon the news — debate, or analysis.	FINANCE:	Stock Market reports, commerce, trading etc.
INFO:	Program the purpose of which is to impart advice in the widest sense.	CHILDREN:	Programs targeted at a young audience.
SPORT:	Program concerned with any aspect of sports.	SOCIAL:	Programs about sociology, history, geography, psychology and society.
EDUCATE:	Educational programs.	RELIGION:	Religious programs.
DRAMA:	All radio plays and serials.	PHONE IN:	Involving members of the public expressing their views either by phone or at a public forum.
CULTURE:	Programs concerning any aspect of national or regional culture, including language, theatre, etc.	TRAVEL:	Travel information.
SCIENCE:	Programs about natural sciences and technology.	LEISURE:	Programs about recreational activities.
VARIED:	Used for mainly speech-based programs like quizzes, panel games and personality interviews.	JAZZ:	Jazz music.
POP M:	Commercial music of current popular appeal.	COUNTRY:	Songs which originate from, or continue the musical tradition of the American Southern States.
ROCK M:	Rock music.	NATION M:	Current popular music of the nation or region in that country's language.
M.O.R.M:	Current contemporary music considered to be "easy-listening."	OLDIES:	Music from the so-called "golden age" of popular music.
LIGHT M:	Instrumental music, and vocal or choral works.	FOLK M:	Music which has its roots in the musical culture of a particular nation.
CLASSICS:	Performances of major orchestral works, symphonies, chamber music, etc.	DOCUMENT:	Program concerning factual matters, presented in an investigative style.
OTHER M:	Music not fitting into any of the other categories.		

Classification of the PTY codes for some FM stations may be different from the above list.

Troubleshooting




If you are having a problem with your unit, check this list for a possible solution before calling for service.

If you cannot solve the problem from the hints given here, or the unit has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom	Cause	Action
Unable to cancel the display demonstration.	Other buttons are pressed to cancel the display demonstration.	Press CANCEL/DEMO on the unit. (See page 8.)
No sound is heard.	Connections are incorrect or loose.	Check all connections and make corrections. (See pages 6 to 8.)
Hard to listen to broadcasts because of noise.	<ul style="list-style-type: none"> Antennas are disconnected. The AM (MW) loop antenna is too close to the unit. The FM antenna is not properly extended and positioned. 	<ul style="list-style-type: none"> Reconnect the antennas correctly and securely. Change the position and direction of the AM (MW) loop antenna. Extend the FM antenna at the best position.
The disc sound is discontinuous.	The disc is scratched or dirty.	Clean or replace the disc. (See page 29.)
The carrousel does not open or close.	<ul style="list-style-type: none"> The AC power cord is not plugged in. The carrousel is locked. 	<ul style="list-style-type: none"> Plug the AC power cord. Unlock the carrousel. (See page 21.)
The disc does not play.	The disc is placed upside down.	Place the disc with the label side up.
The MP3 disc does not play.	<ul style="list-style-type: none"> No MP3 files are recorded on the disc. MP3 files do not have the file extension—.MP3, .Mp3, .mP3, or .mp3 in their file names. MP3 files are not recorded in the format compliant with ISO 9660 Level 1 or Level 2. 	Replace the disc.
The readout time of the MP3 disc is too long.	The readout time varies with the complexity of the recording configuration.	Do not use too many hierarchies and folders when recording. Also, do not record any other types of audio tracks together with MP3 files. (See page 15.)
The cassette holders cannot be opened.	Power supply from the AC power cord has been cut off while the tape was running.	Turn on the unit.
Impossible to record.	Small tabs on the back of the cassette are removed.	Cover the holes with adhesive tape.
Operations are disabled.	The built-in microprocessor may malfunction due to external electrical interference.	Unplug the AC power cord and then plug it back in.
Unable to operate the unit from the remote control.	<ul style="list-style-type: none"> The path between the remote control and the remote sensor on the unit is blocked. The batteries are exhausted. 	<ul style="list-style-type: none"> Remove the obstruction. Replace the batteries.

Specifications

Design and specifications are
subject to change without notice.



CA-MXGB6

Amplifier section

Output Power

- SUBWOOFERS** : 130 W per channel, min. RMS, driven into 6 Ω at 63 Hz with no more than 10% total harmonic distortion.
(IEC268-3)
50 W per channel, min. RMS, driven into 6 Ω at 63 Hz with no more than 0.9% total harmonic distortion.
(DIN)
- MAIN SPEAKERS** : 70 W per channel, min. RMS, driven into 4 Ω at 1 kHz with no more than 10% total harmonic distortion.
(IEC268-3)
48 W per channel, min. RMS, driven into 4 Ω at 1 kHz with no more than 0.9% total harmonic distortion.
(DIN)

Audio input sensitivity/Impedance

(at 1 kHz, measured at MAIN SPEAKERS)

AUX : 400 mV/50 k Ω

Speakers/Impedance : Subwoofers : 6 Ω – 16 Ω
Main speakers : 4 Ω – 8 Ω

Tuner

- FM tuning range : 87.50 MHz – 108.00 MHz
AM (MW) tuning range: 522 kHz – 1 629 kHz

CD player

- CD Capacity : 3 CDs
Dynamic range : 85 dB
Signal-to-noise ratio : 85 dB

Cassette deck

Frequency response

Normal (type I): 50 Hz – 14 000 Hz

Wow and flutter : 0.15% (WRMS)

General

- Power requirement : AC 230 V~, 50 Hz
Power consumption : 230 W (at operation)
27 W (on standby; with power saving off—Normal Mode)
2.8 W (on standby; with power saving on—Eco mode)
Dimensions (approx.): 270 mm x 317 mm x 480 mm (W/H/D)
Mass (approx.) : 11.6 kg

Supplied accessories

See page 6.

CA-MXGB5

Amplifier section

Output Power

- SUBWOOFERS** : 120 W per channel, min. RMS, driven into 6 Ω at 63 Hz with no more than 10% total harmonic distortion.
(IEC268-3)
50 W per channel, min. RMS, driven into 6 Ω at 63 Hz with no more than 0.9% total harmonic distortion.
(DIN)
- MAIN SPEAKERS** : 60 W per channel, min. RMS, driven into 4 Ω at 1 kHz with no more than 10% total harmonic distortion.
(IEC268-3)
46 W per channel, min. RMS, driven into 4 Ω at 1 kHz with no more than 0.9% total harmonic distortion.
(DIN)

Audio input sensitivity/Impedance

(at 1 kHz, measured at MAIN SPEAKERS)

AUX : 400 mV/50 k Ω

Speakers/Impedance : Subwoofers : 6 Ω – 16 Ω
Main speakers : 4 Ω – 8 Ω

Tuner

- FM tuning range : 87.50 MHz – 108.00 MHz
AM (MW) tuning range: 522 kHz – 1 629 kHz

CD player

- CD Capacity : 3 CDs
Dynamic range : 85 dB
Signal-to-noise ratio : 85 dB

Cassette deck

Frequency response

Normal (type I): 50 Hz – 14 000 Hz

Wow and flutter : 0.15% (WRMS)

General

- Power requirement : AC 230 V~, 50 Hz
Power consumption : 220 W (at operation)
27 W (on standby; with power saving off—Normal Mode)
2.8 W (on standby; with power saving on—Eco mode)
Dimensions (approx.): 270 mm x 317 mm x 480 mm (W/H/D)
Mass (approx.) : 11.1 kg

Supplied accessories

See page 6.

